












































**重要!保留以備參照，
請詳細閱讀**













使用產品前請仔細閱讀本說明書，
並妥善保存說明書以便日後參考。

















Designed
around your life

目錄

產品資訊	3
保固與售後服務	
保固條件	
適用範圍	3
警告	4
產品組件及各部件名稱	6
產品安裝	7
符合人體工學的抱嬰姿勢	7
產品使用	7
臉朝內正向式	7
新生兒頸椎保護墊	
臉朝外正向式	8
後背式	8
配件	9
安撫口水墊	
肩帶口水墊	
頭部護罩	
防風罩	
置物包	
收納袋	
維護、保養與保存	9
English (EN)	11

產品資訊

產品名稱: _____

生產日期: _____

保固與售後服務

產品於保固期間內發生問題，請與零售商聯絡；若零售商無法提供服務，他們會聯絡當地的Nuna經銷商。

請留意產品生產日期布標上的產品型號與生產日期序號。

當有保固需求時，請提供以上產品資訊。

請至
www.nunababy.com/tw/gear-registration
網站登記您購買的產品。

保固條件

保固始於產品購買日，我們提供維修服務，但不提供產品退換。保固期限不會因零件更換或維修而延長。

Nuna有權利針對產品進行改善設計，此前製造的產品則無更換義務。

相關保固資訊，詳見官網
www.nunababy.com/tw/warranty

產品名稱	CUDL klik 多功能揹帶
淨重	1公斤
主要材質	塑膠(PP, PA, POM)、 布(聚酯纖維, 棉)、 五金(鋅合金, 不銹鋼, 磁鐵)
原產地	中國

適用範圍

請參閱以下說明，此揹帶共有四種模式，請詳閱各模式對照之適用範圍(最小年齡及最大體重)。

此揹帶符合 EN 13209-2:2015
ASTM F2236-16a
CNS 16006-2:2017

- 1- 臉朝內正向式/嬰兒模式
3.5-7公斤(8-15磅) 最小年齡0個月，最大體重7公斤
- 2- 臉朝內正向式
7-13.5公斤(15-30磅) 最小年齡4個月，最大體重13.5公斤
- 3- 臉朝外正向式
9-13.5公斤(20-30磅) 最小年齡6個月，最大體重13.5公斤
- 4- 後背式
11-15公斤(25-33磅) 最小年齡9個月，最大體重15公斤



警告

跌落及窒息危險

跌落危險 - 嬰兒可能從腿部開口處跌落，請按照指示使用。

- 嬰幼兒可能從腿部開口處滑落，請確認腿部開口調整扣已調至合適大小。
- 使用揹帶前，請確認所有扣具已扣緊、所有調整織帶已固定。
- 嬰幼兒以及照護者之移動，可能對照護者之平衡產生不利影響。
- 照護者彎腰或前傾時須特別小心。
- 揹帶適用於休閒活動，運動時不得使用。
- 此揹帶只適用於體重3.5公斤(8磅)至15公斤(33磅)的嬰兒。

窒息危險 - 4個月以下的嬰兒在此款揹帶中若臉部緊貼大人身體會引致窒息。

- 切勿將嬰兒過緊地束縛在大人身上。
- 為嬰兒頭部活動留下足夠空間。
- 確保嬰兒臉部任何時候都不會被遮蓋。

警告

使用前請檢查所有扣具、調整揹帶、鈕扣及拉鏈皆是安全的。

使用前請檢查是否有磨損、撕裂或扣具毀壞的跡象。

若零件遺失或損壞，停止使用揹帶。

嬰兒頭部還不能直立豎起前，嬰兒臉部須朝向大人。

請確保嬰兒妥善地置於揹帶內，包括雙腿位置。

請確保嬰兒的雙腿在使用揹帶時按照說明分開坐好，雙臂從手臂孔位穿出。

使用揹帶時，需時刻注意嬰兒手臂、腿部及腳部不被揹帶束縛。後背式背法時請加倍注意。

預防跌落危險，請確保嬰兒於揹帶內的姿勢是正確的。

揹帶穿戴完成前請全程用手承托嬰兒。

嬰兒模式僅適用於承載3.5公斤(8磅)至7公斤(15磅)的嬰兒且嬰兒需要面對大人。

早產兒、呼吸有困難及少於四個月的嬰兒最容易引起窒息。

對於出生體重低的嬰兒及進行醫療的嬰幼兒，建議使用本產品之前，先諮詢醫療專業人員之意見。

使用揹帶時務必隨時注意嬰幼兒。

注意居家環境之危害，例：熱源、熱飲濺出。

謹防熱飲噴濺至揹帶中的嬰兒。

嬰幼兒以及照護者之移動，可能對照護者之平衡產生不利影響。

此揹帶僅可由健康成人於行走、站立或坐立時使用。

揹帶適用於休閒活動，運動時不得使用。

配戴心律調整器大人請勿使用此揹帶。揹帶上的磁扣會與您的心律調整器產生干擾。

運動、困倦或身體狀況影響平衡時請勿使用此揹帶。

進行會接觸熱源或化學品的活動例如烹飪或清潔時，請勿使用此揹帶。


駕駛或乘坐機動車輛時請勿使用此揹帶。

嬰兒在揹帶中時請勿躺下或睡眠。

產品組件及各部件名稱

組裝前請確認所有部件已經齊全，如有遺漏，請與銷售商聯繫。本產品無需工具進行組裝。

- | | | |
|-------------|---------------|-------------------------|
| 1 肩帶磁扣 | 10 肩帶 | 18 頭部護罩收納袋 |
| 2 肩帶磁扣接口 | 11 遮頭護罩扣 | 19 新生兒頸椎保護墊拉鏈 |
| 3 肩帶磁扣調整織帶 | 12 肩帶固定扣 | 20 置物包 |
| 4 頸椎保護墊固定鈕扣 | 13 肩帶調整織帶 | 21 收納袋 |
| 5 腿部空間調整扣 | 14 腰帶 | 部件名稱 |
| 6 側帶磁扣 | 配件 | 22 新生兒高度墊
(拉鏈解開/不使用) |
| 7 胯部空間調整扣 | 15 安撫口水墊 (x2) | 23 新生兒高度墊
(拉鏈拉上/使用) |
| 8 胯部空間調整繩 | 16 肩帶口水墊 | |
| 9 防風罩 | 17 新生兒頸椎保護墊 | |



產品安裝

依照嬰兒的最小年齡及最大體重，請依照說明書安裝新生兒頸椎保護墊。

！ 新生兒頸椎需使用(小於4個月)

- 1- 臉朝內正向式/嬰兒模式
3.5-7公斤(8-15磅) 最小年齡0個月，最大體重7公斤
- 2- 臉朝內正向式
7-13.5公斤(15-30磅) 最小年齡4個月，最大體重13.5公斤
- 3- 臉朝外正向式
9-13.5公斤(20-30磅) 最小年齡6個月，最大體重13.5公斤
- 4- 後背式
11-15公斤(25-33磅) 最小年齡9個月，最大體重15公斤

符合人體工學的抱嬰姿勢

髖關節保護

CUDL cliik 榮獲國際髖關節發育不良協會(IHDI)認證，背寶寶時能維持正確姿勢，有效的保護寶貴髖關節。

使用揹帶時，應維持嬰兒雙腿自然的彎曲姿勢以保護髖關節及膝關節，符合人體工學的M型腿姿勢可減少髖關節所受到的壓力。

脊椎保護

使用揹帶時，應給予適當的支撐力，讓嬰兒脊椎呈現自然的C型。

產品使用

- 1- 打開腰帶扣具。(1)
- 2- 將肩帶磁扣、肩帶固定扣及側帶磁扣扣好。(2) (綠色圈起處)
- 3- 將揹帶置於前方，雙手穿過肩帶。(3)
- 4- 將揹帶抬起並將肩帶固定扣越過頭部。(4)
- 5- 確認肩帶固定扣已扣上(藍色圈起處)，調整肩帶固定扣的高度及寬度至舒服的位置，肩帶固定扣應位於兩側肩骨中間。(5)
- 6- 將腰帶環繞於腰部後方，扣上腰帶扣具。(6)

移除揹帶，請依照以上指示反向操作。調整腰帶時，將腰帶往外拉可調緊(7)，拉動腰帶調整扣可調鬆(8)。

！ 當您的孩子還在揹帶內時，請勿將揹帶移除。

展開揹帶

- 1- 解開兩邊肩帶上的磁扣。(9)
- 2- 解開兩邊側帶磁扣。(10)
- 3- 揹帶已展開。(11)

腿部空間調整方式

- 1- 如果您的孩子已超過7kg，則不需使用腿部空間調整扣，請將調整扣解開。(12)

！ 當您的孩子少於7kg時，請務必使用腿部空間調整扣使腿部開口減小成更合適您孩子的空間大小。

磁扣指示標

- 1- 請依照說明使用揹帶，請依循綠色指示標逐一將四個磁扣扣上。請確認磁扣確實將綠色指示標覆蓋。(13)

新生兒高度墊

！ 當您的孩子小於7kg時，請務必使用新生兒高度墊。

- 1- 將新生兒高度墊置於揹帶中(14)
- 2- 將兩邊拉鍊與新生兒高度墊拉上。(15)

當您的孩子大於7kg時：

- 3- 解開新生兒高度墊拉鍊。(16)

臉朝內正向式

- 1- 嬰兒模式
3.5-7公斤(8-15磅) 最小年齡0個月，最大體重7公斤
- 2- 7-13.5公斤(15-30磅) 最小年齡4個月，最大體重13.5公斤

安置嬰兒於揹帶中

！ 以坐姿操作會更加穩定，建議您可以使用坐姿將嬰兒放入揹帶中。

- 1- 將您的揹帶完全展開(當您的孩子小於7kg時，務必使用新生兒高度墊)。(17)
- 2- 依照綠色指示標將單邊的側帶磁扣扣上。(18)

- 3- 用您的手將孩子抱至胸前，用一手將孩子抱好並用另一手將揹帶扶起。(19)
- 4- 將您孩子的雙腿穿過腿部開口安置於適當位置。(20)
- 5- 用一手扶着揹帶並將孩子向您靠近，另一手將另一邊的側帶磁扣依照綠色指示標扣上。(21)
- 6- 用一手扶着孩子，用另一隻手將肩帶磁扣依照綠色指示標扣上，一次扣一個。(22)
- 7- 慢慢地調整磁扣調整織帶長度至適當位置。(23)
- 8- 慢慢的將肩帶調整織帶往斜前方拉至適當長度。(24)
- 9- 確認您的孩子在揹帶裡是舒適的，檢查所有的扣具皆扣好。為孩子的頭部活動留下足夠空間並確保孩子臉部在任何時候都不會被遮蓋。(25)

！ 您的孩子應該要靠近您的身體，並保持在您身體較上方的位置。

！ 請確保您任何時間都可以清楚看到您孩子的臉。

新生兒頸椎保護墊

- 1- 使用於體重介於3.5-7kg的嬰兒，請確認保護墊是安裝好且直立的。將兩側的保護墊鈕扣扣好。這樣可以提供嬰兒頭部及頸部良好的支撐。保護墊以在嬰兒的頸部可以直立撐起頭部時(約4個月)，才可以往下折。(26)
- 2- 如要將保護墊鬆開，將兩側上排的保護墊鈕扣解開即可。(27)
- 3- 將保護墊往下折。(28)
- 4- 將保護墊扣在兩側下排的保護墊鈕扣上。(29)
- 5- 確認您的孩子在揹帶裡是舒適的，檢查所有的扣具皆扣好。為孩子的頭部活動留下足夠空間並確保孩子臉部在任何時候都不會被遮蓋。(30)
- 6- 拉鍊拉開即可將保護墊移除。(31)

臉朝外正向式

- 1- 9-13.5公斤(20-30磅) 最小年齡6個月，最大體重13.5公斤

膝部空間調整繩

- 1- 將膝部空間調整繩拉出。(32)
- 2- 將膝部空間調整繩上的孔位扣上膝部空間調整扣。(33)
- 3- 將新生兒頸椎保護墊下折，使孩子的臉部高於揹帶上緣。您的揹帶已安裝完成。(34)

請參照P.7臉朝內正向式的步驟將您的孩子面朝外安置於揹帶內。

後背式

- 1- 11-15公斤(25-33磅) 最小年齡9個月，最大體重15公斤

後背式姿勢

！ 建議您在實際使用前，先多次練習至熟練。
！ 使用後背式時，切勿使孩子面朝外。

- 1- 以面朝內正向式將您的孩子安置好，放鬆肩帶長度(切勿解開磁扣)。(35)
- 2- 左手抱着孩子，右手從右肩帶上方穿入。(36)
- 3- 換右手抱着孩子，左手從左肩帶調整織帶下方穿入。(37)
- 4- 右手抱好孩子，左手輔助將孩子往右邊轉至右邊腰側。(38)
- 5- 右手抱好孩子，左手將肩帶固定扣往前移動並下拉至胸前。(39)
- 6- 身體向前微傾，並慢慢將孩子移動至背上。(40)
- 7- 右手護着在背上的孩子，左手穿入轉至正面的揹帶調整織帶並將肩帶穿於左肩膀上。(41)
- 8- 換左手護着在背上的孩子，右手從肩帶上方穿入將肩帶穿於右肩膀上。此時兩邊肩帶皆已穿好。(42)
- 9- 慢慢將肩帶調整織帶下拉，將長度調整至適當的位置。上下左右移動調整肩帶固定扣至適當位置。(43)

- 10 - 避免造成困擾，可將過長的肩帶調整織帶捲起，並用織帶尾端的彈力繩固定。(44)
- 11 - 請確認您的孩子在揹帶裡是舒適的，檢查所有的扣具皆扣好。為孩子的頭部活動留下足夠空間並確保孩子臉部在任何時候都不會被遮蓋。(45)

配件

安撫口水墊

- 1- 請先確認新生兒頸椎保護墊是往下折並扣在下排的保護墊扣上。(46)
- 2- 將過長的肩帶磁扣調整織帶收進磁扣下方的小口袋內。(47)
- 3- 將安撫口水墊攤開舖在新生兒頸椎保護墊上，將口水墊扣於下排保護墊扣上。(48)
- 4- 將口水墊往內折，包覆揹帶前緣。(49)
- 5- 將安撫口水墊左右兩端的布料環繞肩帶調整織帶。口水墊應只包覆肩帶調整織帶並介於調整織帶與肩帶之間。(50)
- 6- 使用布料上的黏扣帶將安撫口水墊固定好。調整安撫口水墊至平整併完全包覆揹帶上緣。(51)

肩帶口水墊

- 1- 將新生兒頸椎保護墊鈕扣解開後往下折。(52)
- 2- 將調整織帶尾端收入鈕扣後的口袋裡。(53)
- 3- 將肩帶口水墊置於肩帶與肩帶調整磁扣之間。(54)
- 4- 將肩帶口水墊的鈕扣孔扣在上排的保護墊扣上。(55)
- 5- 將另一端的肩帶口水墊折回，用黏扣帶固定。確保肩帶口水巾是壓在頸椎保護墊下方的。(56)
- 6- 使用相同步驟裝上另一邊的肩帶口水墊。兩邊都安成後，再將新生兒頸椎護墊扣於下排的保護墊扣上。(57)

頭部護罩

- 1- 請先確認新生兒頸椎保護墊是往上立起並扣在上排的保護墊扣上。解開頭部護罩口袋的扣子。(58)
 - 2- 將頭部護罩從口袋中拉出。(59)
 - 3- 將頭部護罩拉至適當位置，遮蓋住孩子的頭部。(60)
 - 4- 將單邊頭部護罩帶上鈕扣對扣於肩帶上的鈕扣，另外一邊亦同。(61)
- ！請確認頭部護罩沒有遮蔽住您孩子的口鼻，也沒有過緊而壓迫到孩子的頭部。

防風罩

- 1- 將防風罩自揹帶底部防風罩收納袋中拉出。(62)
- 2- 將防風罩扣至頸椎保護墊上。(63)

置物包

置物包可以配合產品使用或者單獨使用。(64)

收納袋

揹帶不使用時可置於收納袋。(65)

維護、保養與保存

請參考揹帶上洗滌標版內容的洗滌及乾燥方式。建議使用洗衣網進行洗滌。

長期使用之後，在正常狀況下，布料可能產生褪色、磨損或撕裂。

為確保安全，請使用Nuna原廠零配件。

請定期檢查您的揹帶功能是否正常與零件是否鬆弛磨損或脫落。一旦發生以上任何狀況，請立即停止使用此揹帶。

當長時間不使用揹帶時，請將其存放於陰涼處及寶寶不易接觸的地方。

IMPORTANT!
READ ALL INSTRUCTIONS
CAREFULLY BEFORE ASSEMBLING
AND USING THE SOFT CARRIER.
KEEP INSTRUCTIONS
FOR FUTURE USE

Contents

Product Information	13
Product Registration	
Warranty	
Child Usage Requirements	14
Warnings	15
Parts List	17
Product Set Up	19
Product Use	21
Facing In	22
Head Support	
Facing Out	24
Back Carry	25
Accessories	26
Bib	
Harness Covers	
Hood	
Breeze Cover	
Storage Pocket	
Storage Bag	
Cleaning and Maintenance	27

Product Information

Model Number: _____

Manufactured in (date): _____

Product Registration

Please fill in the above information. The model number and the manufactured in date are located on a label on the product. Fill out the prepaid registration postcard attached to the product and mail it today.

To register your product please visit:

www.nunababy.com

Click the “Register Gear” link on the homepage.

Warranty

We have purposely designed our high-quality products so that they can grow with both your child and your family. Because we stand by our product, our gear is covered by a custom warranty per product, starting from the day it was purchased. Please have the proof of purchase, model number and manufactured in date available when you contact us.

For warranty information please visit:


www.nunababy.com

Click the “Warranty” link on the homepage.


Child Usage Requirements

Please refer to the chart below for proper usage to ensure the safety of your child. There are four carry modes. Mode usage is determined by your child's weight.


Facing In/Infant Booster
8–15 lb (3.5–7 kg)
Birth - 4 months




Facing In
15–30 lb (7–13.5 kg)
4+ months



Facing Out
20–30 lb (9–13.5 kg)
6+ months



Back Carry
25–33 lb (11–15 kg)
9+ months



WARNING

FALL AND SUFFOCATION HAZARD

FALL HAZARD - Infants can fall through a wide leg opening or out of carrier. Follow instructions for use.

- Adjust leg openings to fit baby's legs snugly.
- Before each use, make sure all buckles, fasteners, and adjustments are secure.
- Take special care when leaning or walking.
- Never bend at waist; bend at knees.
- Only use this carrier for children between 8 lb (3.5 kg) and 33 lb (15 kg).

SUFFOCATION HAZARD - Infants under 4 months can suffocate in this product if face is pressed tight against your body.

- Do not strap baby too tight against your body.
- Allow room for head movement.
- Keep infant's face free from obstructions at all times.

WARNING

Check to assure all buckles, snaps, straps, and adjustments are secure before each use.

Check for ripped seams, torn straps or fabric and damaged fasteners before each use.

Stop using the carrier if parts are missing or damaged.

Child must face towards you until he or she can hold head upright.

Ensure proper placement of child in product including leg placement.

Make sure baby's legs are straddling the seat and arms extend through arm holes.

Regularly check that your child is comfortably and securely seated in the baby carrier, especially when using as a back carrier.

To prevent hazards from falling, ensure that your child is securely positioned in the carrier.

Hold your baby closely at all times until correctly attached.

The infant booster must be used for children weighing 8–15 lb (3.5 kg–7 kg) and should **ONLY** be used with your child facing in.

Premature infants, infants with respiratory problems, and infants under 4 months are at greatest risk of suffocation.

For low birth weight babies and children with medical conditions, seek advice from a health professional before using the product.

When using the soft carrier, monitor your child.

Be aware of hazards in the domestic environment e.g. heat sources, spilling of hot drinks.

Take care when bending or leaning forward or sideways.

Your balance may be adversely affected by your movement and that of your child.

This baby carrier is designed for use by adults while walking, standing or sitting only.

This baby carrier is not suitable for use during sporting activities.

DO NOT use this soft carrier if you use a pacemaker, as the magnetic buckles can interfere with the pacemaker.

NEVER use a soft carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.

NEVER use a soft carrier while engaging in activities such as cooking and cleaning which involve a heat source or exposure to chemicals.

NEVER wear a soft carrier while driving or being a passenger in a motor vehicle.

NEVER lie down or sleep with baby in the baby carrier.

Parts List

Make sure all parts are available before assembly. If any part is missing, please contact Nuna. No tools are required for assembly.


- 1 Shoulder Buckle
- 2 Shoulder Buckle Strap
- 3 Shoulder Buckle Adjustment
- 4 Head Support Button
- 5 Leg Hole Adjustment Button
- 6 Side Buckle
- 7 Seat Width Button
- 8 Seat Width Strap
- 9 Breeze Cover
- 10 Shoulder Strap
- 11 Hood Snaps
- 12 Yoke
- 13 Shoulder Adjustment Strap
- 14 Waist Band

Removable Parts

- 15 Bib (x2)
- 16 Harness Covers
- 17 Head Support
- 18 Hood Pocket
- 19 Head Support Zipper
- 20 Storage Pocket
- 21 Storage Bag

Infant Booster

- 22 Infant Booster (Unzipped/Not in Use)
- 23 Infant Booster (Zipped/In Use)




Product Set Up


Based on the chart below, position the head support according to your baby's weight.

! Your baby's head should be supported until he or she has strong head control (approximately 4 months of age).

Facing In/Infant Booster
8-15 lb (3.5-7 kg)
Birth - 4 months




Facing In
15-30 lb (7-13.5 kg)
4+ months



Facing Out
20-30 lb (9-13.5 kg)
6+ months



Back Carry
25-33 lb (11-15 kg)
9+ months




Ergonomic Child Positioning

Hip-Healthy


CUDL™ klik is acknowledged by the International Hip Dysplasia Institute as a hip-healthy product when used as directed.

For hip-healthy babywearing, baby's thighs should be supported from the hip to the knee joint. This ergonomic "M" shape seating reduces forces on the hip joint. Never force baby's legs into a position that is not easily achieved.



Spine-Healthy

For spine-healthy babywearing, proper support is needed. The baby's spine should be allowed to naturally form a "C" shape. Never force baby into a position that is not easily achieved.



Product Use

- 1 - Open the waist band. (1)
- 2 - Make sure both the shoulder buckles and the side buckles are connected (circled in green) (2)
- 3 - Holding the carrier in front of you, slide your arms through the shoulder straps. (3)
- 4 - Pull the carrier over your head. (4)
- 5 - Make sure the yoke is connected (circled in blue). Adjust the height and width of the yoke vertically and sideways to achieve a comfortable fit. The yoke should rest between your shoulder blades. (5)
- 6 - Secure the waist band behind your back, engaging the waist buckle to hold the band firmly in place. (6) To adjust the waist band, pull on the webbing to tighten (7), or pull on the waist band adjuster to loosen (8).

To remove the carrier, reverse the steps above.

! DO NOT remove the carrier while your child is in it.

Opening Baby Carrier

- 1 - Release both shoulder buckles. (9)
- 2 - Release both side buckles. (10)
- 3 - The carrier is open. (11)
- 4 - If your child weighs more than 15 lb (7 kg), the leg hole adjustments are not needed. Slide the leg hole adjustment button out of the button hole on the shoulder strap near the side buckle. (12)

! Leg hole adjustments **MUST** be used for children less than 15 lb (7 kg) to decrease the size of the leg hole and prevent sliding without pinching or chafing your child's leg.

Magnetic Buckle Indicators

- 1 - When following the steps for securing your child, secure all four magnetic buckles by attaching them where you see the green indicators. The buckle must click into place on the raised indicator area. (13)

Infant Booster

! The infant booster **MUST** be used if your child weighs less than 15 lb (7 kg).


- 1 - Locate the unzipped infant booster inside the carrier. (14)
- 2 - Zip the infant booster sides together. (15)

When your child grows out of the infant booster:


- 3 - Unzip the infant booster. (16)

Facing In

Infant Booster
8–15 lb (3.5–7 kg)
Birth - 4 months



15–30 lb (7–13.5 kg)
4+ months



Securing Your Child

! We recommend sitting down while securing your child in the carrier, as it provides better control.

- 1 - Begin with the carrier fully open (and the infant booster secured if your child weighs less than 15 lb [7 kg]). (17)
- 2 - Attach one side buckle where you see the green indicator. (18)
- 3 - Hold your child securely against your chest with one hand, and use the other to raise the front of the carrier. (19)
- 4 - Guide your child's leg down and through the opening between the seat/booster and the attached side buckle. (20)

- 5 - Use one hand to hold the carrier and your child against you, and use the other to secure the other side buckle where you see the **green indicator**. (21)
- 6 - Holding your child in the carrier with one hand, secure the shoulder buckles one at a time where you see the **green indicators**. (22)
- 7 - Gently pull both shoulder buckle adjustments down to adjust the fit. (23)
- 8 - Adjust the shoulder straps by gently pulling both shoulder adjustment straps evenly out in front of you. (24)
- 9 - Make sure your child is comfortable and securely seated in the baby carrier. Adjust the straps around your child and check to make sure all buckles and snaps are secure. Allow room for your child's head movements and keep child's face free from obstructions. (25)
 - ! Your child should be positioned close to you, high on your body.
 - ! Keep your child's face visible to you at all times.

Head Support

- 1 - For a child weighing 8–15 lb (3.5–7 kg), secure the head support so that it is up and supporting the child's head and neck area. Attach the head support to the upper head support buttons. Only fold the head support down when the child is able to hold his or her head up (approx. 4 months). (26)
- 2 - To fold down, slide both upper head support buttons out of the button holes on the head support. (27)
- 3 - Fold the head support down. (28)
- 4 - Attach both bottom head support buttons into the button holes on the head support. (29)
- 5 - Make sure your child is comfortable and securely seated in the baby carrier. Adjust the straps around your child and check to make sure all buckles and snaps are secure. Allow room for your child's head movements and keep child's face free from obstructions. (30)
- 6 - To remove the head support, unzip it from the carrier. (31)

Facing Out

20–30 lb (9–13.5 kg)
6+ months




Seat Width Strap

- 1 - Pull the seat width strap out. (32)
- 2 - Attach the seat width button into the button hole on the seat width strap. (33)
- 3 - Fold the head support down so your child's face will be above the top edge of the carrier. The carrier is now ready for you to secure your child. (34)

Follow the same steps for securement as Facing In mode (page 22), but face your child outward.

Back Carry

25–33 lb (11–15 kg)
9+ months



Back Carry Position

- ! We recommend practicing this method a few times without a child in the carrier before attempting it with your child.
- ! Child should **NEVER** be facing out (away from you) in back carry mode.
- 1 - With your child in the baby carrier facing inward, loosen both shoulder adjustment straps (**DO NOT unbuckle**). (35)
- 2 - Slide your right arm out of the right shoulder strap while cradling your child with your left arm. (36)
- 3 - Slide your left arm under the shoulder adjustment strap on the side while cradling your child with your right arm. (37)
- 4 - Cradling your child with your right arm, guide your child to your right hip using your left arm. (38)
- 5 - Still supporting your child, grab the shoulder strap with your left hand and pull it down over your shoulder. (39)
- 6 - Slightly lean forward and move your child onto your back. (40)
- 7 - Slide your left arm up through the shoulder adjustment strap on the side while cradling your child behind your back with your right arm. (41)
- 8 - Slide your right arm down through the shoulder strap while cradling your child with your left arm. Both shoulder straps should now be secure around your shoulders. (42)

- 9 - Pull down on the shoulder adjustment straps to tighten. Adjust the yoke up or down vertically and side to side. (43)
- 10 - Roll up the excess length of the shoulder adjustment straps and use the elastic loop to wrap around the rolled up strap to store it out of the way. (44)
- 11 - Make sure your child is comfortable and securely seated in the baby carrier. Adjust the straps around your child and check to make sure all buckles and snaps are secure. Allow room for your child's head movements and keep child's face free from obstructions. (45)

Accessories

Bib

- 1 - Make sure the head support is folded down and secured in place with the lower head support buttons. (46)
- 2 - Store the extra length of the shoulder buckle adjustment in the pocket on the shoulder buckle strap. (47)
- 3 - Cover the front of the head support with the front of the bib and slide both head support buttons through the button holes on the bib. (48)
- 4 - Fold and tuck the bib over the top edge of the head support. (49)
- 5 - Wrap both side edges of the bib around the shoulder buckle strap. The back edge of the bib is slid between the shoulder strap and shoulder buckle strap. The front edge of the bib is laid over the shoulder buckle strap. (50)
- 6 - Attach the sides of the hook and loop. Make sure the bib is laying flat and is secure to the top edge of baby carrier. (51)

Harness Covers

- 1 - Unbutton the head support and fold it down. (52)
- 2 - Store the extra length of the shoulder buckle adjustment in the pocket on the shoulder buckle strap. (53)
- 3 - Slide the harness cover between the shoulder strap and the shoulder buckle strap. (54)
- 4 - Slide the button on the shoulder buckle strap through the button hole on the harness cover. (55)
- 5 - Attach the hook and loop. Make sure the bottom edge of the harness cover is tucked behind the head support. (56)
- 6 - Repeat on the other side. When both harness covers are secure, attach both bottom head support buttons into the button holes on the head support. (57)

Hood

- 1 - Make sure the head support is up and secured in place with the upper head support buttons. Undo the snap on the pocket located on the top edge of the head support. **(58)**
 - 2 - Pull the hood out of the hood pocket. **(59)**
 - 3 - Adjust the hood to the desired position to shade your child. **(60)**
 - 4 - Attach three snaps on the hood strap to the three snaps on the shoulder strap. Repeat for the other side. **(61)**
- ! Make sure the hood is not covering your child's mouth or laying too tightly over their head.

Breeze Cover

- 1 - Unroll breeze cover from pocket at the bottom of the carrier when needed. **(62)**
- 2 - Attach breeze cover by fastening to head support button. **(63)**

Storage Pocket

Storage Pocket can be tied to waist band or used separately. Pocket can be used with product or separately. **(64)**

Storage Bag

CUDL klik can be stored in storage bag. **(65)**

Cleaning and Maintenance

Refer to the care label attached to the carrier fabric for washing and drying instructions. Carrier **MUST** be washed inside a mesh laundry bag.

It is normal for fabric to fade from sunlight and to show wear and tear after a long period of use, even when used normally.

For safety reasons, only use original Nuna parts.

Check regularly that everything functions properly. If any parts are torn, broken, or missing, stop using this product.